

Communication system

- [Ethernet Driver](#)
 - [Setup of Embedded Ethernet](#)
 - [Sending your first message](#)
 - [Ethernet Testing](#)
 - [Extra Functions](#)
 - [Debugging](#)
 - [Issues](#)
- [Protobuffers](#)
 - [Starting with Protobufs](#)
 - [Design](#)
 - [Arm Board Protobuffers](#)
 - [Sensor Board Protobuf](#)
 - [Driving Board Protobuffers](#)

Ethernet Driver

The documentation for the embedded Ethernet driver

Setup of Embedded Ethernet

This page: How to set up ethernet.

Introduction

Ethernet is the protocol used to communicate between all the components. It uses the **auto-generated Ethernet driver** code from cubeMX to use the physical Ethernet peripheral. It also uses **LWIP** to do the lowest levels of packet handling. Lastly, we use **freeRTOS** for multi threading. The current implementation cannot work without it.

CubeMX

CubeMX is used to automatically generate setup code for the stm32. To use Ethernet you have to set up a few things in cubeMX.

To write this driver I mostly used videos from ControllersTech on YouTube. The most useful video is [STM32 Ethernet \(Part 1\): How to configure Ethernet peripheral and perform successful ping test](#) [1]. So if you do not understand anything, watch that video.

1) ETH

ETH is under connectivity in cubeMX. It sets up the Ethernet peripheral. Set it to  mode.

[afbeelding.png](#)

NVIC > NVIC

Turn on Ethernet global interrupt in NVIC settings.

[afbeelding.png](#)

ETH > GPIO settings

When Ethernet is enabled, the pins should **automatically** be configured according to the below schematic. This can be wrong, please **confirm it!**

Setup all the PINS like it is done in the [PIN schematic](#) (Download: [MB1364-H753ZI-C01 Board schematic](#), pg. 6) [2].

[afbeelding.png](#)

[afbeelding.png](#)

Troubleshooting: Pins not set as schematic

If any of the pins are not as in the schematic, refer to the above information. You can click each pin in CubeMX and choose the correct function (e.g. ETH_RXD0), the other (incorrect) pin will be automatically disabled.

2) LWIP

LWIP is a middleware generated by cubeMX. You can find it under middleware.

LWIP > Platform Settings

Set up LAN8742, to signal that that is the physical Ethernet driver you use.

[afbeelding.png](#)

LWIP > General settings

[afbeelding.png](#)

The most important configurations here are the DHCP (**DHCP = Disabled**) and IP address settings. The IP address settings **don't matter**, they will be **overwritten** in a configuration file in the code.

LWIP > Key options

The most important part of the tab *Key options* is to check if `LWIP_ARP = Enabled`. You also need to keep track of the `MEM_SIZE` (Heap Memory Size). Start with a value of `1024*16` bytes.

`LWIP_RAM_HEAP_POINTER` should be `0x30004900` such that the heap doesn't overlap different memory. That is the value I use, but it can be changed if need be.

Lastly, you need to add `ETHARP_SUPPORT_STATIC_ENTRIES = Enabled`. This is only shown when you turn on Show Advanced Parameters.

[image.pngimage.png](#)

3) CORTEX_M7

You can find *CORTEX_M7* under System Core.

CORTEX_M7 > Parameter Settings

Turn on `CPU ICache` and `CPU DCache`.

[image.png](#)

Setup memory protection like seen below:

[afbeelding.png](#)

The `MPU Region Base Address` is the address of the first Rx descriptor (*ETH > Parameter Settings > General*). The `MPU region size` is calculated using heap memory size and the RX buffers. Watch the [video](#) [1] mentioned above for more information.

[afbeelding.png](#)

4) FreeRTOS

Freertos is automatically integrated in LWIP if you turn it on in cubeMX. It does not have to be modified, it just has to be turned on. Make sure you use `CMSIS_V2`, because V1 did not work well.

NOTE: when you use FreeRTOS, you will have to select **another SYS Timebase Source**. Go to *SYS > Timebase Source* and select any of the free timers, just make sure it is **NOT** SysTick. Make sure you do not use that timer for any other activities.

Make sure you set your `TOTAL_HEAP_SIZE` to a sufficient number. When it is not big enough, the threads that you will create using FreeRTOS will suffocate and not work. This will also not give you any errors so watch out for it!

The Code

After you generate the code for your board, you can look through networking component, in the `ethernet.h` file, to see all public Ethernet functions.

For a full guide of how to use Ethernet, I refer you to [Driver usage](#) [3].

Resources

1. [STM32 Ethernet \(Part 1\): How to configure Ethernet peripheral and perform successful ping test](#)
2. [PIN schematic](#) (Download: [MB1364-H753ZI-C01 Board schematic](#), pg. 6)
3. [Driver usage](#)

Sending your first message

This page: how to initialize your Ethernet driver and send your first message. A lot of constants can be seen in the explanatory code. Those can be found in `components/common/networking_constants`. They are also added at the end of this file.

The functions that are used for Ethernet can be found in `components/common/networking/inc/ethernet.h`.

The headers in the folder `components/common/networking/stm/` are only to be used inside the Ethernet driver!

NOTE: The implementation only works with FreeRTOS, but it works fine with only 1 thread. **Before you implement anything, do an introductory tutorial on FreeRTOS!**

Code Usage

1) Linker file updating

In the linker file, you need to say what memory addresses LWIP uses. You set these values in Cubemx and the sections are generated for you, but you have to add it to the linker file yourself.

You can find your linker (`.ld`) file in `components/{env_name}/firmware/`

The codeblock added for the default values is:

```
.lwip_sec (NOLOAD) :
{
    . = ABSOLUTE(0x30000000);
    *(.RxDecripSection)
```

```
. = ABSOLUTE(0x30000080);
*(.TxDecripSection)

. = ABSOLUTE(0x30000100);
*(.Rx_PoolSection)

} >RAM_D2
```

You can just use the generated linker file and append to it, because it never gets regenerated, but you can also create a new one. If you create a new one, you have to put in the platformio configuration file that you use the new linker file. An example of how to do it is shown below. The path is relative to where the platformio configuration file is located.

```
board_build.ldscript = components/network_board/firmware/STM32H753XX_FLASH.ld
```

2) Code initialization

When you first use the Ethernet driver, you have to initialize a few things.

First make sure that HAL is initialized, the D and I cache are enabled, the system clock and the memory protection unit as well. These auto-generated functions start processes that Ethernet uses.

```
//Initialize HAL
HAL_Init();

//Enable D&I cache (for ETH)
SCB_EnableICache();
SCB_EnableDCache();

//Start the system clock
SystemClock_config();

//Memory protection unit
MPU_Config_wrapper();
```

Note for debugging with SCB_EnableDCache()

When debugging and trying to step over `SCB_EnableDCache()`, the program will keep infinitely running **unless** you place a breakpoint on the next line **while in active debugging mode**.

ETH_Init(...)

```
result_t ETH_init(linkstatus_callback_t link_state_change_callback,  
                  uint8_t ip[4], uint8_t netmask[4],  
                  uint8_t gateway[4],  
                  uint8_t mac_address[6])
```

For `ETH_init`, the `link_status_change_callback` can be set to `NULL`, to use the default function. The others have to be set. For initial testing you can set these to the same values as set in CubeMX.

Example usage of ETH_init(...)

```
//Example values  
uint8_t ip[4] = {192, 168, 0, 223};  
uint8_t mac[6] = {255, 255, 255, 255, 255, 255};  
uint8_t gateway[4] = {192, 168, 0, 1};  
uint8_t netmask[4] = {255, 255, 255, 0};  
  
ETH_init(NULL, ip, netmask, gateway, mac);
```

NOTE on multithreading: make sure you set the stack size big enough (I use `.stack_size = 1024 * 8`) when setting the `task_attributes` for the thread Ethernet will be running in!

ETH_udp_init()

```
void ETH_udp_init(uint8_t sender_prio_buf,  
                  QueueHandle_t *send_queues,  
                  receive_callback_t receiver_callback)
```

- `sender_prio_buf`

Defines the **number** of priority queues you use for queuing the send messages. The queues we use are freeRTOS queues. More information can be found [here](#).

- `send_queues`

You need to pass freeRTOS queues as a pointer to an array. The queues need to be implemented before passing them to `ETH_udp_init(...)`, see below.

Example queue implementation

```
int SendQueueSize = 80;

//Create queue 1
static StaticQueue_t xStaticQueue1;
uint8_t ucQueueStorageArea1[SendQueueSize * ETHERNET_SQ_ITEM_SIZE]; //NOTE: constants from
<ethernet_constants.h>
QueueHandle_t udp_receiver_queue1 = xQueueCreateStatic(SendQueueSize,
ETHERNET_SQ_ITEM_SIZE, ucQueueStorageArea1, &xStaticQueue1);

//Create queue 2
static StaticQueue_t xStaticQueue2;
uint8_t ucQueueStorageArea2[SendQueueSize * ETHERNET_SQ_ITEM_SIZE];
QueueHandle_t udp_receiver_queue2 = xQueueCreateStatic(SendQueueSize,
ETHERNET_SQ_ITEM_SIZE, ucQueueStorageArea2, &xStaticQueue2);

//queues object we pass as an argument later
QueueHandle_t queues[2] = {udp_receiver_queue1, udp_receiver_queue2};
```

- `receiver_callback`

This can be any function that takes a `receive_frame_t`, found in `ethernet_udp.h`. However, we also implemented a "packet dispatcher", to handle incoming packets.

More information about the packet dispatcher is in the [Packet Dispatcher documentation](#).

Example implementation WITHOUT packet dispatcher

```
void HandlePacket(receive_frame_t *receive_frame) {
    printf("Wayoo, message received");
}

int main(void) {
    ...
}
```

```
/*The other code examples above would go HERE */  
ETH_udp_init(2, queues, HandlePacket);  
  
...  
}
```

Now Ethernet is started and you can **receive packages!**

3) Sending Packets

ETH_add_arp(...)

```
result_t ETH_add_arp(uint8_t ip[4], uint8_t mac[6], int retry_count)
```

To send to a certain IP, you have to set the ARP table. Otherwise, it will only send ARP resolution messages. You do that by using the `ETH_add_arp(...)` function with the IP you want to send to, and any random mac address.

WARNING: Make sure you have initialized udp **before** using `ETH_add_arp(...)`!

ETH_udp_send(...)

```
void ETH_udp_send(uint8_t ip[4],  
                  uint8_t port,  
                  uint8_t *payload,  
                  uint16_t payload_len,  
                  uint8_t prio_num)
```

- `payload`

The payload can be any byte array, where the size of that byte array is the 4th argument: `payload_len`.

- `prio_num`

Priority level for transmission. Must be less than `sender_prio_buf` specified in `ETH_udp_init(...)`.

Now you can send messages!

Example: sending a message

```
//NOTE: These are the receiving ip/mac,  
//not the sending ones we specified earlier  
uint8_t ip[4] = SAMPLE_BOARD_IP;  
uint8_t mac[6] = SAMPLE_BOARD_MAC; //constants from <ip_mac_constants.h>  
  
ETH_add_arp(ip, mac, 5);  
  
uint8_t packet1_payload[4] = {14,06,20,04};  
ETH_udp_send(ip, 8, packet1_payload, 4, 1); //Send a single packet
```

Appendix

1) Networking_constants

```
#ifndef IP_MAC_CONSTANTS  
#define IP_MAC_CONSTANTS  
  
#define SAMPLE_BOARD_IP {192, 168, 0, 111}  
#define SAMPEL_BOARD_MAC {0x00, 0x80, 0xe1, 0x00, 0x00, 0x00}  
  
#define NETWORK_IP {192, 168, 0, 223}  
#define NETWORK_MAC {0x00, 0x43, 0x23, 0xee, 0x21, 0x64}  
  
#define GATEWAY {192, 168, 0, 1}  
#define NETMASK {255, 255, 255, 0}  
#endif //! IP_MAC_CONSTANTS
```

2) Full Example Code

Import "networking_constants.h" and "ip_mac_constants.h" to use the predefined test constants

```
#include "ethernet.h"
#include "networking_constants.h"
#include "ip_mac_constants.h"

/* Callback function that handles a specific packet*/
void HandlePacket(receive_frame_t *receive_frame) {
    printf("Wayoo, message received");
}

int outgoing_counter = 0;
int main(void) {
    /*Inits*/
    HAL_Init();
    SystemClock_Config();

    MPU_Config_wrapper();

    SCB_EnableICache();
    SCB_EnableDCache();

    MX_GPIO_Init();

    /*Config + init sending side*/
    uint8_t mac[6] = NETWORK_MAC;
    uint8_t ip[4] = NETWORK_IP;
    uint8_t netmask[4] = NETMASK;
    uint8_t gateway[4] = GATEWAY;

    ETH_init(NULL, ip, netmask, gateway, mac);

    /*Making queues*/
    int SendQueueSize = 80;

    static StaticQueue_t xStaticQueue1;
    uint8_t ucQueueStorageArea1[SendQueueSize * ETHERNET_SQ_ITEM_SIZE];
    QueueHandle_t udp_receiver_queue1 = xQueueCreateStatic(SendQueueSize,
```

```

ETHERNET_SQ_ITEM_SIZE, ucQueueStorageArea1, &xStaticQueue1);

static StaticQueue_t xStaticQueue2;
uint8_t ucQueueStorageArea2[SendQueueSize * ETHERNET_SQ_ITEM_SIZE];
QueueHandle_t udp_receiver_queue2 = xQueueCreateStatic(SendQueueSize,
ETHERNET_SQ_ITEM_SIZE, ucQueueStorageArea2, &xStaticQueue2);

QueueHandle_t queues[2] = {udp_receiver_queue1, udp_receiver_queue2};

ETH_udp_init(2, queues, HandlePacket);

/*Config + add ARP receiving side*/
uint8_t ip[4] = SAMPLE_BOARD_IP;
uint8_t mac[6] = SAMPLE_BOARD_MAC;

ETH_add_arp(ip, mac, 5);

/*Sending a message*/
uint8_t packet1_payload[4] = {14,06,20,04};

/*Test sending*/
while (outgoing_counter < 100) { //NOTE: after 80 packages the queue will be full!
    ETH_udp_send(ip, 8, packet1_payload, 4, 1);
    osDelay(10);
    outgoing_counter += 1;
    LOGI(TAG, "%d", outgoing_counter);
}
}

```

Ethernet Testing

Send Testing

Requirements

- STM32
- Ethernet Cable
- Wireshark

Testing

Send testing is easy. The only thing you have to do is upload the setup and sending code to your STM32 and connect it to your PC/laptop using an Ethernet cable. Then you can go into Wireshark, look at the activity on you ethernet peripheral, to see if it sends something. It also logs to the terminal if you send, if you have turned logging on.

Receive Testing

Requirements

- Linux laptop ☐☐
- STM32
- Ethernet Cable

Connect the Ethernet cable between the STM and the laptop that is sending you packets.

- Any pcap packet sender
We recommend packeth, installation manual will be below.
- Wireshark (optional)

Installation of Packeth

NOTE: you need a Linux laptop for this

Testing

Receive testing is done by sending packets, saved in test/networking, to the STM32 using a pcap packet sender. If you want to use new packets, I advise to send the packet you want from the STM32. Then use Wireshark to save the packet such that you can send it back. In Wireshark you can see, when you send a package, to which IP and MAC it is being sent, and it should match with your IP and MAC.

To see if the messages are received, make sure you print messages in your receive function. Then check the serial

Extra Functions

Introduction

This documentation is about extra functions, that are not necessary to get it running, but can be used if need be.

Non-deprecated functions

ETH_setup_MAC_address_filtering

This function is used for perfect mac address filtering. It is used by giving it MAC-addresses as arguments. If you receive packets with those addresses, they will also be processed.

Deprecated Functions

There are deprecated functions for raw sending (`ETH_raw_send`) and custom protocol receiving (`ETH_custom_protocol_receiver`). Those can be used if you don't want to use UDP, but I don't know if they still work.

Raw receiving

If you want to receive messages, you need to have `#define LWIP_HOOK_UNKNOWN_ETH_PROTOCOL(pbuf, netif) eth_reader(netif, pbuf)` in the `cubemx_main.h` file.

Debugging

Introduction

This documentation gives some tips on how to debug the Ethernet Driver.

Debug Flags

By setting the flag " LWIP_DEBUG" to 1 in the cubemx main file, you will get extra lwip debug messages in your terminal.

Hard Faults

While debugging, it is easy to use a debugger to go step by step through your code. However, the deeper you go into the code, the bigger the chance that your debugging will trigger an hard fault. So when that happens verify if the hard fault is your doing or not, by debugging less deep while you have a debug point set on the hard fault function, to check if it still hard faults.

Issues

Introduction

There are some issues with ethernet. Those are described here.

The Issues

Arp Table removal

The ARP function will fail when Ethernet is not started properly yet. Current fix is `retry_count` that retries the arp x amount of times.

Protobuffers

Starting with Protobufs

What are protobufs?

[Protocol Buffers](#) (protobufs) are a way to define structured messages in `.proto` files.

The point is simple: define the message format once, generate code for your language, and now everyone agrees what the bytes mean (without inventing a new packet format every semester).

Where they live

The source of truth for RoboTeam message definitions is: [RoboTeamTwente/ERC-Protobufs](#).

Other repositories (embedded, software, tooling) should **consume** these definitions (often via a git submodule) instead of copy-pasting `.proto` files around.

Editing rules (the important part)

Field numbers are the real API

In protobuf, the **field number** is what goes on the wire. Renaming a field is usually harmless; changing its number is usually the problem.

Never renumber an existing field unless you are intentionally breaking compatibility and coordinating the update across all consumers.

Safe changes (usually)

- Add a new field with a **new** unused number.
- Add new enum values (don't reuse old numeric values for new meanings).
- Stop using a field before deleting it, and reserve its number if your style guide does that.

Changes that need extra care

- Changing a field type (e.g. `int32` → `string`).
- Changing semantics/units (mm vs m, degrees vs radians).

Typical workflow

1. Edit / add `.proto` files in `ERC-Protobufs`.
2. Generate / update code as required by your project (this step is repo-specific).
3. Update consumers to use the new fields (and handle missing fields safely).
4. Test at least one real send/receive path.
5. Open a PR that lists: what changed, field numbers, and compatibility expectations.

Troubleshooting

“My message doesn’t parse”

- Confirm both sides use the same (or compatible) `.proto` definitions.
- Check field numbers: no reuse, no renumbering.
- Check transport framing (length prefix / delimiter / CRC). Protobuf gives bytes; transport still matters.

“It parses, but values are nonsense”

- Check units and semantics (the most common “it’s wrong but not broken” bug).
- Make sure generated code is up to date (stale generated files cause creative failures).

Protobufs are boring on purpose. Boring schemas prevent exciting debugging sessions. Keep changes small, reviewable, and compatible.

Design

This page explains rules that apply to all protobuffers, and a bit on how we use them.

PBEnvelope

All protobuffers are wrapped in the `PBEnvelope` message, which contains metadata we need in all protobufs.

Lost packets & throttling

In every line of communications, the packets must be sent periodically. The frequency of sent packets is indicated in their `PBEnvelope`. If the receiver does not get a packet within given timeout, it means the packet was lost. In most cases this means that the brakes should be engaged for safety.

Arm Board Protobuffers

This page: each *arm_board* protobuffer explained.

The protobuffers for the *arm_board* are passed between software, control and embedded.

Movement_software_target.proto

Software -> control

This file contains two protobuffers detailing the source of a movement.

ArmBoardTargetMovement contains the target coordinates for a movement. This gets sent to control, they use this information to calculate motor angles.

ArmBoardObstructions is a placeholder for now. The idea is that software would be able to pass a list of coordinates of physical obstructions to control, around which they would manoeuvre the movement of the arm.

Movement_control_in.pb.h

Control -> Embedded

After control calculates the angles using the information from the previous protobuf, it sends the control signals back to us (embedded) with the **absolute** angles and frequency for the motors. **So, this is the information embedded uses to actuate the motors.**

ArmboardControlSignals contains all the angles the motors need to be turned to. We then use this information to set the PWM pins.

Movement_software_feedback.proto

Embedded -> Software

After the movement happens (or fails), embedded will send feedback to software for them to calculate the next movement.

ArmBoardMovementFeedback sends an error code to software.

Possible error codes are:

- Point_not_in_range
- Obstruction
- Calibration
- Motor_malfunction
- All_ok

ArmBoardActualPositions sends back the angle of each motor of the arm. Software will use this to display a 3D model of the arm position. (Allegedly)

Motor_diagnostics.proto

Arm board -> Debugging board

This protobuf gets periodically sent to the debugging board to indicate the status.

ArmBoardDiagnostics the `MotorInformation` for each motor and the state of the **entire** board.

Possible states are:

- Idle
- Operating
- Calibrating
- Errored

MotorInformation is a common protobuf shared between all boards that use motors (this and driving board). MotorInformation contains the state (same as above), motor_id, rpm, voltage and encoder_angle for a single motor.

Sensor Board Protobuf

This page: Complete protobuf message definitions for the `sensor_board` component.

The protobuffers for the `sensor_board` are passed between embedded, the network, and other boards for diagnostics and data collection. This page documents the actual message definitions from the ERC-Protobuffs repository.

Common Definitions (sensor.proto)

Location: `ERC-Protobuffs/components/sensor_board/sensor.proto`

SensorState Enum

Shared across all sensor types - indicates the current operational state of a sensor.

```
enum SensorState {  
    SENSOR_IDLE = 0;           // Sensor is idle/not currently sampling  
    SENSOR_OPERATING = 1;      // Sensor is actively sampling/operating normally  
    SENSOR_CALIBRATING = 2;    // Sensor is in calibration mode  
    SENSOR_ERROR = 3;          // Sensor has encountered an error  
}
```

GPS Sensor (gps_sensor.proto)

Location: `ERC-Protobuffs/components/sensor_board/gps_sensor.proto`

Direction: `Sensor Board` → `Navigation/Localization Systems`

GPSFixQuality Enum

Indicates the type and quality of GPS fix obtained.

```
enum GPSFixQuality {
    NO_FIX = 0;           // No fix available
    GPS_FIX = 1;          // Standard GPS fix
    DGPS_FIX = 2;         // Differential GPS fix
    PPS_FIX = 3;          // PPS (Pulse Per Second) fix
    RTK_FIX = 4;          // Real-Time Kinematic fix
    RTK_FLOAT = 5;        // RTK float solution
}
```

GPSErrorCode Enum

Detailed error codes for GPS/GNSS sensor failures.

```
enum GPSErrorCode {
    GPS_NO_ERROR = 0;
    GPS_COMMUNICATION_FAILURE = 1; // UART connection lost
    GPS_INVALID_DATA = 2;          // Data parsing or validation failed
    GPS_ANTENNA_FAULT = 3;         // GPS antenna disconnected or faulty
    GPS_LOW_SIGNAL_QUALITY = 4;    // Signal strength too weak for fix
}
```

SensorBoardGPSInfo Message

Complete GPS positioning and velocity information.

```
message SensorBoardGPSInfo {
    // GPS coordinates
    double latitude = 1;           // Degrees (positive = North, negative = South)
    double longitude = 2;          // Degrees (positive = East, negative = West)
    float altitude = 3;            // Meters above sea level

    // Velocity data
    float speed = 4;               // Speed in meters per second
    float heading = 5;             // Course over ground in degrees (0-360)

    // Position accuracy and quality
    float hdop = 6;               // Horizontal dilution of precision (lower is better)
    float vdop = 7;               // Vertical dilution of precision (lower is better)
    int32 satellites = 8;         // Number of satellites in view (up to 16)
```

```
GPSFixQuality fix_quality = 9;

SensorState state = 10;
GPSErrorCode error_code = 11;  // Error code if state is SENSOR_ERROR

// Timestamp from GPS
int64 utc_timestamp = 12;      // Unix timestamp in milliseconds
}
```

IMU Sensor (imu_sensor.proto)

Location: ERC-Protobufs/components/sensor_board/imu_sensor.proto

Direction: Sensor Board → Motion Control/Attitude Systems

IMUErrorCode Enum

Detailed error codes for IMU sensor failures.

```
enum IMUErrorCode {
  IMU_NO_ERROR = 0;
  IMU_COMMUNICATION_FAILURE = 1;      // I2C/SPI connection lost
  IMU_CALIBRATION_REQUIRED = 2;       // Sensor needs calibration
  IMU_CALIBRATION_FAILED = 3;         // Calibration procedure failed
  IMU_INVALID_DATA = 4;               // Data out of valid range
  IMU_SENSOR_FAULT = 5;               // Hardware fault detected
  IMU_GYROSCOPE_ERROR = 6;            // Gyroscope component failure
  IMU_MAGNETOMETER_ERROR = 7;         // Magnetometer component failure
  IMU_ACCELEROMETER_ERROR = 8;        // Accelerometer component failure
}
```

SensorBoardIMUInfo Message

3-axis inertial measurement data (acceleration, angular velocity, magnetic field).

```
message SensorBoardIMUInfo {
  // 3-Axis Accelerometer data
```

```

float accel_x = 1;           // X-axis acceleration
float accel_y = 2;           // Y-axis acceleration
float accel_z = 3;           // Z-axis acceleration

// 3-Axis Gyroscope data
float gyro_x = 4;            // X-axis angular velocity
float gyro_y = 5;            // Y-axis angular velocity
float gyro_z = 6;            // Z-axis angular velocity

// 3-Axis Magnetometer data (9-axis IMU only)
float mag_x = 7;             // X-axis magnetic field
float mag_y = 8;             // Y-axis magnetic field
float mag_z = 9;             // Z-axis magnetic field

bool is_calibrated = 13;     // True if IMU has been calibrated on level surface

SensorState state = 14;
IMUErrorCode error_code = 15; // Error code if state is SENSOR_ERROR
}

```

pH Sensor (ph_sensor.proto)

Location: ERC-Protobufs/components/sensor_board/ph_sensor.proto

Direction: Sensor Board → Environmental Monitoring Systems

PHErrorCode Enum

Detailed error codes for pH sensor failures.

```

enum PHErrorCode {
  PH_NO_ERROR = 0;
  PH_COMMUNICATION_FAILURE = 1;           // ADC connection lost
  PH_OUT_OF_RANGE = 2;                   // Reading outside 0-14 range
  PH_CALIBRATION_REQUIRED = 3;           // Sensor needs calibration
  PH_INVALID_DATA = 4;                   // Data validation failed
  PH_PROBE_FAULT = 5;                   // Electrode fault detected
  PH_TEMPERATURE_SENSOR_ERROR = 6;       // Temperature compensation sensor failed
}

```

```
}
```

SensorBoardPHInfo Message

Water quality measurement with temperature compensation.

```
message SensorBoardPHInfo {  
    float ph_value = 1;           // Raw pH measurement (0-14 scale, 7 is neutral)  
    float voltage = 2;           // Voltage reading from pH sensor in millivolts  
    float temperature = 3;       // Temperature reading in Celsius (if external sensor  
    available)  
  
    SensorState state = 4;       // Current state of the pH sensor  
    PHErrorCode error_code = 5;  // Error code if state is SENSOR_ERROR  
}
```

Notes:

- pH value is derived from voltage via linear calibration equation
- 40-sample moving average applied internally to reduce ADC noise
- Temperature used for automatic compensation (default ~25°C)

Load Cell Sensor (load_cell.proto)

Location: ERC-Protobufs/components/sensor_board/load_cell.proto

Direction: Sensor Board → Arm Control/Gripper Systems

LoadCellErrorCode Enum

Detailed error codes for load cell sensor failures.

```
enum LoadCellErrorCode {  
    LOAD_CELL_NO_ERROR = 0;  
    LOAD_CELL_COMMUNICATION_FAILURE = 1;  // ADC connection lost  
    LOAD_CELL_OUT_OF_RANGE = 2;           // Force measurement exceeds limits  
    LOAD_CELL_CALIBRATION_REQUIRED = 3;   // Sensor needs calibration  
    LOAD_CELL_INVALID_DATA = 4;           // Data validation failed  
}
```

```
LOAD_CELL_SENSOR_FAULT = 5;           // Hardware fault detected
}
```

SensorBoardLoadCellInfo Message

Force measurement for robotic gripper control and load monitoring.

```
message SensorBoardLoadCellInfo {
  uint32 sensor_index = 1;           // 0-based index of the load cell (0 or 1)
  float force_newtons = 2;           // Force in Newtons
  float mass_grams = 3;              // Mass in grams (derived from force)
  int32 raw_counts = 4;              // Raw ADC counts (for debugging)

  // Calibration status and parameters
  bool is_calibrated = 5;            // True if calibration parameters are valid
  float scale_newtons_per_count = 6; // Conversion factor (N/count)
  int32 tare_offset_counts = 7;      // Zero-load ADC offset

  SensorState state = 8;
  LoadCellErrorCode error_code = 9;  // Error code if state is SENSOR_ERROR
}
```

Dual Sensor Support:

- Up to 2 independent load cells (sensor_index 0 and 1)
- Typically used on dual-pad grippers for load distribution feedback
- Each sensor maintains independent calibration parameters
- Enables slip detection via load imbalance analysis

Pressure Sensor (pressure_sensor.proto)

Location: ERC-Protobufs/components/sensor_board/pressure_sensor.proto

Direction: Sensor Board → Arm Control/Gripper Systems / Environmental Monitoring

PressureErrorCode Enum

Detailed error codes for pressure sensor failures.

```
enum PressureErrorCode {
    PRESSURE_NO_ERROR = 0;
    PRESSURE_COMMUNICATION_FAILURE = 1;    // I2C/ADC connection lost
    PRESSURE_OUT_OF_RANGE = 2;             // Reading exceeds sensor limits
    PRESSURE_CALIBRATION_REQUIRED = 3;     // Sensor needs calibration
    PRESSURE_INVALID_DATA = 4;             // Data validation failed
    PRESSURE_SENSOR_FAULT = 5;             // Hardware fault detected
}
```

SensorBoardPressureInfo Message

Pressure measurement for robotic gripper control and environmental sensing.

```
message SensorBoardPressureInfo {
    uint32 sensor_index = 1;                // 0-based index of the pressure sensor (0 or 1)

    // Pressure data
    float pressure_kpa = 2;                  // Pressure in kilopascals
    float temperature_c = 3;                 // Temperature in Celsius (if available)
    float voltage = 4;                       // Sensor output voltage (if available)

    // Calibration status
    bool is_calibrated = 5;                  // True if calibration parameters are valid

    SensorState state = 6;
    PressureErrorCode error_code = 7;        // Error code if state is SENSOR_ERROR
}
```

Dual Sensor Support:

- Up to 2 independent pressure sensors (sensor_index 0 and 1)
- Primary use: gripper pad force feedback for PID control
- Enables real-time grip force regulation and slip detection
- Secondary uses: depth sensing, altitude sensing, system pressure monitoring

Board Diagnostics (diagnostics.proto)

Location: *ERC-Protobuufs/components/sensor_board/diagnostics.proto*

Direction: *Sensor Board → Debugging Board / Health Monitoring Systems*

SensorBoardDiagnostics Message

Complete system health and status snapshot sent periodically (5 second default).

```
message SensorBoardDiagnostics {
  enum State {
    IDLE = 0;
    OPERATING = 1;
    CALIBRATING = 2;
    ERROR = 3;
  }

  State state = 1;                // Overall board state
  SensorBoardPHInfo ph_sensor = 2; // pH sensor status
  SensorBoardIMUInfo imu_sensor = 3; // IMU sensor status

  // Overall sensor board health
  float board_temperature = 4;    // Board temperature in Celsius
  float board_voltage = 5;        // System voltage (3.3V supply)

  SensorBoardGPSInfo gps_sensor_1 = 6; // GPS sensor status
}
```

Board States:

- **IDLE (0)** - Board initialized but not actively polling sensors
- **OPERATING (1)** - All sensors functioning normally, data being collected
- **CALIBRATING (2)** - Board or sensors in calibration mode
- **ERROR (3)** - Critical system failure detected

Health Indicators:

- **board_temperature** - STM32H753 die temperature; normal range 25-75°C
 - **board_voltage** - 3.3V supply input; should be 3.0-3.6V
 - **Embedded sensor states** - Each sensor's current SensorState (IDLE/OPERATING/CALIBRATING/ERROR)
-

Error Code Pattern

All sensor error codes follow a consistent pattern:

```
enum XXXErrorCode {  
    XXX_NO_ERROR = 0;                // No error  
    XXX_COMMUNICATION_FAILURE = 1;    // Hardware interface (I2C/SPI/UART/ADC) failure  
    XXX_OUT_OF_RANGE = 2;            // Reading outside valid sensor range  
    XXX_CALIBRATION_REQUIRED = 3;     // Sensor needs calibration  
    XXX_INVALID_DATA = 4;            // Data validation/filtering failed  
    XXX_SENSOR_FAULT = 5;            // Hardware fault or component failure  
    // Additional sensor-specific errors...  
}
```

Integration into application:

```
if (gps_result.error_code == GPS_COMMUNICATION_FAILURE) {  
    LOG_ERROR("GPS UART connection lost");  
    diagnostics.gps_sensor_1.state = SENSOR_ERROR;  
} else if (gps_result.error_code == GPS_NO_ERROR) {  
    LOG_INFO("GPS position: %f, %f", gps_result.latitude, gps_result.longitude);  
}
```

Network Transmission

Main Sensor Data:

- Sent via individual sensor messages
- Packaged into SensorBoardState (sensor.proto)
- UDP broadcast to 192.168.0.255:7 (configurable)
- Interval: 5 seconds default (configurable)
- Encoding: Nanopb (lightweight protobuf for embedded)

Diagnostics Data:

- Sent via SensorBoardDiagnostics message
- UDP broadcast to 192.168.0.255:7 (same port)
- Interval: 5 seconds (syncd with main loop)
- Contains snapshot of all sensor states + health metrics

Message Composition

The SensorBoardDiagnostics message is composed of individual sensor message types:

```
SensorBoardDiagnostics
├─ state (Board state)
├─ SensorBoardPHInfo
│   ├─ ph_value
│   ├─ voltage
│   ├─ temperature
│   ├─ state (SensorState)
│   └─ error_code (PHErrorCode)
├─ SensorBoardIMUInfo
│   ├─ accel_x, accel_y, accel_z
│   ├─ gyro_x, gyro_y, gyro_z
│   ├─ mag_x, mag_y, mag_z
│   ├─ is_calibrated
│   ├─ state (SensorState)
│   └─ error_code (IMUErrorCode)
├─ board_temperature
├─ board_voltage
└─ SensorBoardGPSInfo
    ├─ latitude, longitude, altitude
    ├─ speed, heading
    ├─ hdop, vdop, satellites
    ├─ fix_quality
    ├─ state (SensorState)
    ├─ error_code (GPSErrorCode)
    └─ utc_timestamp
```

Note: Not all proto files define load cells and pressure sensors in diagnostics.proto yet - they are sent as separate messages when available.

Driving Board Protobuffers

This page: each *driving_board* protobuffer explained.

The protobuffers for the *driving_board* are passed between software, control and embedded.

DrivingBoardDiagnostics.proto

Embedded → Software / Debugging

This file contains the full diagnostic state of the driving board and all attached motors.

DrivingBoardDiagnostics is the main status message used to report the system state and motor-level health information.

DrivingBoardDiagnostics

This message contains:

- Overall board state (IDLE, OPERATING, CALIBRATING, ERROR)
- Motor information for all driving and steering motors

The board state is used to indicate the current operating mode of the driving board.

MotorInformation fields:

Each motor is reported using the MotorInformation protobuf, which includes:

- motor state
- motor ID
- RPM
- voltage
- encoder angle

Motors included The diagnostics message explicitly contains 10 motors: front_left_motor middle_left_motor back_left_motor front_right_motor middle_right_motor back_right_motor steering_front_left_motor steering_back_left_motor steering_front_right_motor steering_back_right_motor

Notes: This structure is currently fixed-size, meaning all motors are explicitly defined instead of using a repeated field.

DrivingBoardMotorMessage.proto

Software → Embedded

This message is used to send motion commands to the driving board.

DrivingBoardMotorMessage Contains high-level movement instructions:

- distance_to_go → target travel distance
- turning_radius

Purpose: This message defines a movement request from software. The embedded system uses it as input to compute values on the control code.

DrivingBoardMotorPeriodicProgress.proto

Embedded → Software

This message provides runtime feedback during movement execution.

DrivingBoardMotorPeriodicProgress

Contains:

- distance_left → remaining distance to target

Purpose This message allows software to track progress of an ongoing movement command in real time. It is typically sent periodically while a movement is being executed.